

# Texecom



**User Guide**

**INS549-2**



# Contents

<b>Contents .....</b>	<b>2</b>	<b>Menu Commands .....</b>	<b>41</b>
<b>Introduction .....</b>	<b>3</b>	<b>Tool Bar Commands .....</b>	<b>42</b>
Installation .....	3	<b>Panel Language Editor Premier 412/816/ &amp; 832 .43</b>	
Starting Wintex .....	3	Introduction.....	43
<b>User Logon.....</b>	<b>4</b>	Enable Panel Language Editor .....	43
User Details .....	5	Using Panel Language Editor .....	44
System Access .....	5	Starting Translation .....	45
Panel Access .....	6	Inserting Special Characters .....	46
<b>Accounts/Customers .....</b>	<b>7</b>	IMPORTANT NOTES.....	46
Creating a New Account/Customer .....	7	Updating the Panel Language .....	47
Customer Details.....	7	<b>Language Manager for Wintex™ .....</b>	<b>48</b>
Panel Details.....	8	Starting Translation .....	48
Panel Information .....	9	Creating a New Language .DLL file.....	49
Open or Alter an Existing Account.....	10	Notes for Translation.....	49
Editing an Account .....	11	Future Versions of WINTEX™ .....	49
Saving Account Data.....	11		
Viewing Account History.....	11		
Print Account & Panel Details .....	12		
Backup Account Data.....	12		
Restoring accounts .....	13		
<b>Connection Options .....</b>	<b>14</b>		
Connect Locally.....	14		
Connect Remotely.....	15		
Modem Information.....	17		
Adding a New Modem.....	18		
Texecom USB Modem.....	20		
Wintex Options .....	22		
<b>Programming the Control Panel .....</b>	<b>23</b>		
Zones & Attributes.....	23		
Programming Areas/Partitions Timers & Options .24			
Programming Global System Options .....	25		
Remote Keypad Options.....	26		
Programming Expander Options.....	27		
Programming Outputs.....	28		
Programming Communications Options.....	29		
Programming Users .....	30		
<b>Connecting with the control panel .....</b>	<b>31</b>		
Waiting for the Panel to Call.....	31		
Requesting a Call Back.....	31		
Disconnecting from the Control Panel .....	31		
<b>Sending &amp; Receiving Configuration Data .....</b>	<b>32</b>		
Receiving .....	32		
Sending .....	34		
<b>Diagnostics .....</b>	<b>36</b>		
Online Status & Control.....	36		
Online Keypad .....	37		
Event Log .....	37		
Remote/Anti Code Reset .....	38		
Online Printer.....	39		
<b>Changing the Language .....</b>	<b>40</b>		

## Introduction

**Wintex™** is a user-friendly Windows™ based software, designed for use with the **Premier & Premier Elite** Series of control panels, and provides complete upload/ download and systems diagnostics for total control and flexibility. The programme can be used whether connected to a Control Panel or not, to create panel profiles and add and delete customers etc...

Windows is a registered trademark of Microsoft Corporation

## Installation

**Wintex™** will function on any Windows PC with an operating system that is XP/2000/Vista & Seven. 32 Bit and 64Bit systems are supported.

**Wintex™** can be downloaded from the Texecom website providing you are a Registered Installer. Please visit <http://www.texe.com> to register.

**Wintex™** will be installed in C:\Programme Files\Texecom where C: is the designated hard drive. In the case of 64 bit systems, the programme will be installed in C:\Programme Files (x86)\Texecom.

Once installation is complete you can use Wintex for the first time.

## Starting Wintex

To open the program click on the Icon created during setup, if you chose not to create an Icon the application can be started from the programme list under the Texecom folder.



The following window will appear.



# User Logon

By default there is no requirement to log on to the programme once opened: it is strongly recommended that you assign individual user names and passwords for any person who will utilise the programme.

## User Configuration

Click on User Change User Access. The following screen will appear.

By default you are now on the Master user screen. The user name is Master and the default password is 123456. You should change the password from the default as anybody could gain access to the system and control panel accounts. The Master User account has all options enabled by default and cannot be deleted.

To add a new user click on the Add New User button, the following will appear:-

Enter a user name and a six digit password and press OK.

The following screen will appear and you can now change the attributes for the user you are creating.

## User Details

### User

#### Change user name

use the dropdown list to edit the users name

### User options

#### User enabled

If this is selected the user can log in and use Wintex

#### Enable User expiry

If a date is set against said user after this date the user will not be allowed to log in.

#### Add New User

(Please see previous page)

#### Delete User

This will allow you to delete all details associated with the programmed user.

## Password Options

### Minimum Password

This is the minimum length of the password required

### User Must Change Password


If this option is selected the next time the user logs in they must change their password

### Enable Password Expiry

If this is selected on and a date is set against said user after this date the user will not be allowed to log in because the password has been deleted.


## System Access

If you have more than one user on the system you may want to alter the attributes associated with users, the following can be changed for each user of the system.



## Panel Access

As with System Access, you can customise each user to allow or deny access to any of the listed Panel Access Options.



Once you have completed all of the required changes click OK.

The next time you open **Wintex™** you will be prompted to log on.

# Accounts/Customers

## Creating a New Account/Customer

Click Accounts, New Account...press CTRL+N or press the new button.



The New Account Details window is displayed

## Customer Details

It is possible to create a new account with just an Account Ref, however it is recommended you include as much detail here as possible, this will make it easier to manage the database as it grows.

### File Name

This will be generated from the Account Ref

### Account Reference.

This can contain up to 25 characters in length.

### Name

Enter the Name of the customer.

### Address

Enter the customer Address details.

### Postcode

Enter the Post Code

### Tel No:

Enter the customer contact telephone number

### Fax:

Enter the Fax number

### Notes:

Enter any other customer information (E.G. site specific information)

## Panel Details

Click on the Panel Details tab to enter the panel information.

### Up to V6

### V6.16 & Later

## Panel Details

### Panel Type:

From the drop down list, select the Control Panel type that is fitted at site.

### Software Version

From the drop down list, select the software version that is fitted in the Control Panel. If you do not know the version select the latest (highest number). The first time you connect with the Control Panel, Wintex will prompt you if the software version in the account mismatches the version in the Control Panel.



NOTE If your panel software version is higher than that available in the drop down list, make sure you have the latest version of **Wintex™** installed.

### Serial Number

The Serial Number box will initially be blank, this will be automatically updated the first time you connect with the Control Panel.

### UDL Password

Enter the UDL passcode that is programmed in the Control Panel at site. If one has not been set, it will be the last 4 digits of the engineers code.



NOTE *this must be programmed*

### Date Installed

Enter the date that the Control Panel was installed (optional)

### LCD Display Type

select the Keypad type that is fitted at site (standard or International)

### Include Zone Text on Send/Receive

Check this box to send/receive all zone text

### Include All Zones on Send/Receive

In the Panel Tel No. entry box, enter the telephone number (including STD code) for the line that the Control Panel is connected. If you are using the USB-Com Module/IP module you may leave this blank.

### Include All Radio Config when Sending Data\*

If Wireless Technology is fitted to the control panel check this box

### Include All Ricochet Config when Sending Data (V6.13 & Later)

Check this box to SEND data the panel when using **Ricochet™ MT2** Technology on **Premier Elite** panels



NOTE \*If this box is not checked and **Ricochet™** devices are installed no data will show in **Wintex**



## Panel Modem Details

### Panel Modem Type

From the drop down list, select the modem type that is fitted to the control panel



**NOTE** if none is fitted please leave as com300

### Panel Telephone Number

enter the telephone number (including STD code) for the line that the Control Panel is connected to. If you are using the USB-Com /IP module you may leave this blank.

### Always Connect at 300 baud

If there is a RedCare STU connected to the same telephone line as the Control Panel then make sure the Always Connect at 300 Baud box has a tick in it (click on it to toggle). This will force PC modem to communicate at 300 Baud, which is the speed that RedCARE recommend to ensure that the modems do not corrupt the STU data. If this option is "greyed" out the Control Panel is only capable of communicating at 300 Baud.

### Enable 2-Call Answer Phone Defeat

If the Control Panel has been programmed to uses the 2-Call Answer phone defeat option (this is a default parameter), then make sure the Enable 2-Call Answer Phone Defeat box has a tick in it (click on it to toggle). This will force the PC modem to dial out wait then hang up after a pre-programmed delay then dial out again. The Control Panel will only pick up the call on the second time the PC dials out. This allows the Control Panel to be used on the same telephone line as other equipment e.g. fax machines, telephones and answer phones. To program the 2-Call Answer Phone Defeat Delay, see Modem Configuration on page 16

## Radio Pad Details

### Radio-Pad NUA

If the panel is fitted with a Radio-Pad and you have a Radio-Pad connected to your PC you can communicate with the panel using the Paknet network. Enter the NUA number of the Radio-Pad that is fitted to the panel in the Radio-Pad NUA input box.

### Radio-Pad NES

Enter the NES details for the Radio-Pad.

## Network Details

### Host Address

If the panel is fitted with a COM-IP or a COM-GSM using a fixed IP SIM card, fill in the IP address

### Host Port

Fill in the Port number associated with the IP address from above.

### Connect via WebWayOne SMG

If the panel is using a WebWayOne or Emizon 21 module the check this box.

## Panel Information

### Panel Information

Shows details of the installed panel.

### Software History

Shows details of major changes to the Control Panels firmware, and the relevant release number.

Click OK to save the account details, this account is now open and you can alter the programming parameters of the control panel.

## Open or Alter an Existing Account

### Customer Accounts

Click Accounts, Open Account... press CTRL+O or select the open button.



Account Ref	Name	Address	Site Tel No	Radio-Pad NUA	Panel Type	Version
Test Customer 1	Wayne Robertson	42 Chicken Lane En...	32323455677		Premier 168	7.x
Test Customer 11	Bill Thomas	123 Bench Street En...	4556322334		Premier 832	1.x
Test Customer 12	Bob Max	Steve Street Englan...	3445656736		Premier 88	9.x
Test Customer 121	Andy Woodcock	88 Monitor Lane Eng...	344536473567		Premier 816	15.x
Test Customer 13	Thomas Clive	12 Jenkins Drive Engl...	0123456789		Premier 24	8.x
Test Customer 16	Fitz Jerald	23 Oldham Rd Englan...	01706233875		Premier 832	13.x
Test Customer 17	Wayne Rabbit	82 Load Lane Englan...	234523432423		Premier 88	8.x
Test Customer 18	James Sparow	11 Country Lane En...	568656345		Premier 168	9.x
Test Customer 18	Mark Clive	71 Yule Way Englan...	4513453145		Premier 168	10.02
Test Customer 19	Alan Mell	77 Suagr Coar Englan...	492392302		Premier 48	7.x
Test Customer 19	Steve Asfa	44 Well Rd England ...	5465656564		Premier 48	10.x
Test Customer 2	Andy Heath	212 Vile RD England ...	076543212345		Premier 816	6.x
Test Customer 22	Shelly Hall	98 FairFax Lane Eng...	35245745687		Premier 48	9.x
Test Customer 23	Mick Jackswon	63 Rod Lane Englan...	75434534665		Premier 640	9.x
Test Customer 23	Richard Flan	77 New Year Drive E...	64562345625		Premier 48	9.x
Test Customer 24	Nick Heat	44 Red Rd England ...	4566234523		Premier 168	9.x
Test Customer 25	Steve Carol	90 Grange Rd Englan...	6456523423		Premier 88	7.x
Test Customer 29	Stuart Rich	33 Road Lane Englan...	01706233875		Premier 24	7.x
Test Customer 3	Stepth Moon	42 Oak Way Englan...	1234556789		Premier 88	3.x
Test Customer 30	Conor Mustard	82 Elm Street Englan...	09876543456		Premier 48	7.x
Test Customer 30	Jack Beavis	23 Head Road Englan...	979764343		Premier 48	9.x
Test Customer 32	Kerry Agate	55 Drive Rd England...	4547873467		Premier 24	8.x
Test Customer 4	James Higgins	22 Road Lane Englan...	9998887777		Premier 640	9.x
Test Customer 41	John Mac	11 River Street Engl...	01706233875		Premier 168	5.x
Test Customer 52	Paul Reed	1 Perfect Road Engl...	67564534231		Premier 24	8.x
Test Customer 6	Paul Pfau	29 Trailer Park Lane ...	09856434323		Premier 816	14.x
Test Customer 7	Paul Smith	64 Zoo lane England	77384737434		Premier 48	7.x

Number of Accounts: 29

Click on the account that you want to use.

#### Delete

delete the selected account.

#### New

Opens the window to create a new account, see previous section.

#### Search

Allows free text search of the following fields:-

- Account Ref
- Name
- Address
- Postcode
- Site Tel No
- Radio-Pad NUA
- Panel Type

#### Show All

Use this button if your search parameters do not find the correct account

#### Print

Prints a list of the accounts shown in the account window.

#### Email

to send the profile of the selected account via email (default program Microsoft™ Outlook)

#### Open

open the selected account.

#### Cancel

cancels the action and closes the window

## Editing an Account

Open the Account you wish to Edit.



Click Accounts; Edit Account... press CTRL+E or press the edit button.

The Edit Account Details window is displayed:

From here you can edit all the settings that have previously saved/stored.



NOTE please see 'Creating a new customer on page 7 for details on how and what to change

## Saving Account Data

After making any changes to the accounts programming, the Accounts, Save Account option is enabled. To save changes to disk:



Click on the Save button on the main tool bar (Or press CTRL+S)



NOTE Wintex will prompt you to save the account before it closes, if you do not want to save your changes select "No"

## Viewing Account History


Click Accounts, Account History.... The Customer History window is displayed:

Date	Time	Group	Description
05/12/2011	15:10:30	File	Account opened by user Master
05/12/2011	15:10:47	Receive	Control Panel data Received by user: Master
05/12/2011	15:11:34	Receive	Control Panel data Received by user: Master


Use the scroll bar to scroll up/down through the customer history.

Click on the Close button when finished.

## Print Account & Panel Details


Click Accounts, Print Account & Panel Details... press CTRL+P or click on the Print button. 

The Print Options window is displayed:



Select the options you require to print.


Click on the Print button, the Print window is displayed:



Select the Printer you wish to send the print job to and then click on the OK button.


## Backup Account Data

Click Accounts|Backup Account Data... The Account Data Backup window is displayed.



If you are backing the account data onto a removable media (floppy disk) then insert the disk into the drive.

Click Browse... to select the location of the backup folder:




Click on the required drive/folder and click OK to accept.


Click start to copy the opened account data to the backup location.

## Restoring accounts

This feature can be used if you import an account from another computer or from a USB stick,  
Click Accounts, Restore Account Data... The Account Data Restore window is displayed.




Click Browse... to select the location of the restore folder:



Click on the required drive/folder and click OK to accept.

Click Read Disk to read the available accounts on the restore disk. The accounts and information will be displayed:



Click (Ctrl + Click to multi-select) on the accounts you want to restore.

Click Restore to restore the selected accounts.



**NOTE** if the account is locked with a password, please contact technical support.

# Connection Options

Connection can be achieved either locally or remotely. First you need to set up the connection method or methods that are to be used.


## Connect Locally

### PC COM

If you are using a PC com this will be at default assigned to Com1, as this is a serial device, no drivers will be needed for this device.

### USB Com


Connect the USB com to your PC and to one of the Com ports on the Control panel. Windows™ will automatically install the required drivers. If the drivers do not automatically install, they can be located in the folder that Wintex has been installed in, for example C:\Programme Files\Texecom\Wintex\FTDI Drivers\. To install the drivers use the Update Driver function in Device

Manager. The device that needs updating will be shown with this symbol 

Once the drivers have been installed the USB Com be automatically assigned to an available Com Port on your PC, to see which com-port is being used by your PC go to 'Device Manager' and look under 'Ports' (It will be read by the PC as a 'USB Serial Port') The port number assigned will be between 1 & 16



**NOTE** The com port will only show once the USB Com is connected to the panel and has power.




## Assign the correct Port

When using either the PC Com or the USB Com you must tell **Wintex™** which port number to use.

Click Setup, Setup Modem...press CTRL+M or select the button 'setup'  Setup.

The Modem Settings and Options window is displayed, at this point select the PC Com Tab. This tab is used for both the PC-Com and the USB Com.



Using the drop down box you can select which com-port is being used, once the selection is made select 'OK'.



**NOTE** this is not the com-port of the control panel, this is the comport being used by the PC.

## Com IP

When connecting via IP you should first make sure you have entered the correct details in the Panel Details Tab of the customer account. This can be found on Page 9. You will also need to ensure the Control Panel has been configured correctly. Please see the relevant Control Panel installation manual, and the instructions that came with the Com-IP.




**NOTE** When connecting locally via IP you must either plug the Com-IP into a router, or if directly connecting to Com-IP from the PC use a crossover cable.

## Modem Settings & Options TCP/IP

### Ricochet™ Monitor Connection (V6.13 & later only)

This box is used to determine which port to use to connect to Ricochet™ Monitor, and should only be used when connection to V2.XX Elite panels and V2.XX Expanders.



**NOTE** Under normal circumstance there will be no need to change the packet size & Packet Time-Out options shown above.

## Connect Remotely

Connection can be made remotely in a number of ways, this section details the requirements for each connection type.


## Com IP

To setup the IP connection, please see the previous section for regarding the setup for Local IP connection, the principle is basically the same.

## Radio-Pad Connection

Click Setup, Setup Modem...press CTRL+M or select the button 'setup' .

The Modem Settings and Options window is displayed, at this point select the Radio Pad tab;



Using the drop down select which com-port is to be used.

To program the Radio-Pad Number to be used for connection please see Radio-Pad setup on page 9

## Connect via Com GSM

### Connect over GSM

To connect to the Control Panel via GSM you will need a SIM card with data services enabled, and a Modem for your PC. The Data Number should be entered into the as the Panel Tel No. See page 9 for details. Also see the installation manual for the COM-GSM.

### Connect over GPRS (IP)

To connect via GPRS you will need a fixed IP SIM card, you will be given the IP address and Port number by your service provider. Enter the relevant details in the customer account. See page 9 for details. Also see the installation manual for the COM-GSM.

### Connect via WebWayOne SMG


If the control panel is fitted with a WebWayOne module make sure you have programmed this correctly on the control panel, and entered the relevant details in the Customer Account. See page 9 and make sure to check the Tick Box.

### Modem Connection



Click Setup, Setup Modem...press CTRL+M or select the button 'setup' .

The Modem Settings and Options window is displayed.



### Modem Options

#### Connect Using

Select the Com Port that the modem is connected to. This can be set to Com1 - Com 16 (this will be the comport number of your USB on your PC, this can be obtained from device manager on your PC when the modem is connected and powered)

#### Baud Rate


Select the Baud Rate that the modem will use.

#### Modem Type

Select the Modem type from the drop down selection box.



**NOTE** When you select a modem the Configuration String for the selected modem is also loaded and displayed in the Configuration String edit box. If required the selected modem may be edited by clicking on the 'Edit Modem button'. This will display all configuration information for the selected modem:





## Modem Information

### Commands

#### Name

The Name of the selected modem. ( This cannot be changed through Wintex)

#### Initialize

The command used to reset the modem, normally ATZ ^ M.

#### Dial

The command used to dial, normally ATD.

#### Dial suffix

The command used to initiate the dialling sequence, normally ^ M.

#### Cancel Dial

The command used to cancel a dialling attempt, normally ^ M.

#### Hangup

The command used to hang up the modem, normally ~~~+++~ATH0 ^ M.

#### Answer

The command used to answer an incoming call, normally ~ATA ^ M.

#### Configure

The custom configuration string see Modem Configuration String Guidelines below

#### V21

The parameter for 300 baud speed used by the panel, normally S37=3

#### V22bis

The parameter for 2400 baud speed used by the panel, normally S37=6

### Return Codes

#### Okay

The modem response to a valid command, normally OK.

#### Connect

The modem response when connected with another modem, normally CONNECT.

#### Busy

The modem response when a busy line is detected, normally BUSY.

#### Voice

The modem response when a voice response is detected, normally VOICE.

#### No Carrier

The modem response when a carrier could not be detected, normally NO CARRIER.

#### No Dialtone

The modem response when a no dial tone is detected, normally NO DIALTONE.

#### Error

The modem response to an invalid command, normally ERROR.


#### Ring

The modem response when ringing is detected, normally RING. Adding a new Modem

## Adding a New Modem


### Modem Database

Click Setup/Modem Database you will be presented with the following screen




### Add

Click Add you will be presented with the following screen



Type the name of the new modem and then click OK.

The New Modem is now in the list of available modems, select it and click on edit The screen will appear as follows with default values added.



Edit the relevant fields to add the details supplied by your modem manufacturer and click OK.

Your New Modem is now ready to use.

## Editing the Modem INI file

You can add a new modem by editing the modem INI file which is located in the following directory.

C:\Program Files\Texecom\Wintex

To add a new modem open the file and add the name of the modem to the list.



**NOTE** after the name of the modem you need to add =#

```

[Index]
Blank Test=#
Generic Hayes=#
Cardinal 2400 MNP=#
Dynamlink 1414VQH=#
Everex 12e External (EV-936)=#
Everex 24e External (EV-945)=#
Hayes Personal Modem 2400=#
Hayes SmartModem 1200 External=#
Hayes SmartModem 1200B Full=#
Hayes SmartModem 1200B Half=#
Multi-Tech ZDX=#
USR Password 1200 internal=#
USR Sportster 14400=#
ZOOM/Modem 14400 FAX/modem=#
ZOOM/Modem K56 Flex=#
Pace Linnet 34 Plus=#
Pace Mobi Fax=#
USR 56K Voice win (Int.)=#
USR 56K Voice win (Ext.)=#
Motorola SM56 PCI SPEAKERPHONE=#
USR Sportster 33.6 Fax Modem=#
ESS ES56 CHV-PI *=#
BT Speedway=#
SpeedCom+=#
Billion 56Kbps External=#
Multi-Tech MT5600 ZDXE=#
Creative Modem Blaster USB=#
USR 56K Faxmodem (Model 5630)=#
USR 56K Message Modem=#

```

After saving the file if you go back to **Wintex™** you will see the modem you have added.

Once the new modem is in the drop down list, you can make any changes required to the Modem Setup as shown on the previous page.

## Texecom USB Modem

The *USB-Modem* has been specifically designed for use with Wintex UDL software and a PC to allow trouble free uploading/downloading with *Premier* control panels.

### System Requirements

The following are the minimum requirements required for the *USB-Modem* to work properly with your computer:

- 133 MHz or faster Intel® Pentium® or AMD® processor
- 10 MB free hard disk space
- 16 MB RAM (32 MB or higher recommended)
- Microsoft® Windows® 98 Second Edition (SE), Windows 2000, Windows Millennium Edition (ME), Windows XP, Windows Vista or Windows 7
- DVD/CD-ROM drive for modem software installation

### USB-Modem Layout

The *USB-Modem* has only two connectors, one, the USB Connector, and two, the Telephone Line Jack. No extra power connector is needed as the unit is a USB-powered device that draws power from the computer's USB port.




Figure 1. *USB-Modem* Indicators and Connectors

**Telephone Line Jack:** Connect the telephone supplied into this socket and plug the other end into a telephone wall socket.

**USB Connector:** Connect the smaller end of the supplied USB cable into the USB Connector. Connect the other end into one of the computer's USB ports.

**Power/Data Indicator:** This indicator is lit when the *USB-Modem* is powered from the USB port. The indicator flickers when the *USB-Modem* is sending or receiving data.

## Installation

### USB Driver Installation

The *USB-Modem* requires a driver to be installed onto the computer before it can be used. The *USB-Modem* uses the same driver as the *USB-Com*, the driver can be found on the Wintex CD in the **D:\USB-Com** folder or alternatively it can be downloaded from the Texecom web site [www.texecom.com](http://www.texecom.com).

If you are already using a *USB-Com* with the computer then driver will already be installed and you can skip steps 2 - 7.

### Windows 98SE and Windows ME

1. Connect the *USB-Modem* into a USB port on the PC. Turn on your computer to allow the Operating System to detect the *USB-Modem*.
2. When detected the **Add New Hardware Wizard** screen appears:



3. If you are using the drivers from the Wintex CD insert the CD into your DVD/CD-ROM drive. Then click the **Specify the location of the driver (Advanced)** option and click the **Next** button.
4. Click the **Specify a location** check box. Then, click the **Browse** button to locate the driver files in **D:\USB-Com\Win98ME** (where D: represents your DVD/CD-ROM drive). Ensure that the **Removable Media (Floppy, CD-ROM...)** check box is not selected:




5. Click the **Next** button, the following screen appears:



6. Click the **Next** button, the following screen appears:



7. Click the **Finish** button to complete the *USB-Modem* installation.
8. The *USB-Modem* will be assigned a virtual com port, to find out which port number has been assigned to the *USB-Modem*, open the **Device Manager** (press the **⌘ + Break** on your keyboard) and expand the **Ports (COM & LPT)** option. You should see the **USB Serial Port** and its com port number, COM6 in the example below:



- The *USB-Modem* is now installed and ready for use with Wintex UDL software, see Modem Connection on page 16

**Windows XP and Windows 2000**

- Connect the *USB-Modem* into a USB port on the PC. Turn on your computer to allow the Operating System to detect the *USB-Modem*.
- When detected the **Found New Hardware Wizard** screen appears:



- If you are using the driver from the Wintex CD insert the CD into your CD-ROM/DVD drive. Then click the **Install from a list or specific location (Advanced)** option and click the **Next** button.
- Click the **Include this location in the search** check box. Then, click the **Browse** button to locate the driver files in **D:\USB-Com\Win2kXP** (where D: represents your DVD/CD-ROM drive). Ensure that the **Search removable Media (Floppy, CD-ROM...)** check box is not selected:




- Click the **Next** button, the following screen appears:



- Click the **Finish** button to complete the USB High Speed Serial Converter installation.
- After a short delay the **Found New Hardware Wizard** screen will appear again:



- Repeat steps 4 to 7 to install the USB Serial Port driver.
- The *USB-Modem* will be assigned a virtual com port, to find out which port number has been assigned to the *USB-Modem*, open the **Device Manager** (press the **Win** + **Break** on your keyboard) and expand the **Ports (COM & LPT)** option. You should see the **USB Serial Port** and its com port number, COM3 in the example below:



- The *USB-Modem* is now installed and ready for use with Wintex UDL software, see Configuring Wintex Software.

**Windows Vista and Windows 7**

- Connect the *USB-Modem* into a USB port on the PC. Turn on your computer to allow the Operating System to detect the *USB-Modem*.
- The new hardware should be detected automatically and the drivers will be installed.
- If the drivers are not automatically installed open Device Manager and right click on the Unknown device listed under Ports Com & LPT, click update driver and brows to the location of the drivers on the CD.

**Earlier Versions of Wintex**

The *USB-Modem* can be configured for use with earlier releases of Wintex. In order to do so, you need to create two modem driver entries in Wintex, one for use with the *Com-300* and one for use with the *Com-2400*:

*Com-300* Configuration Setting: **ATFC1S99=44S30=64^M\***

*Com-2400* Configuration Setting: **ATFC1S99=44S30=4^M\***

## Specifications

### Electrical

Operating Voltage:	5V <sub>DC</sub>
Current Consumption:	30mA
Modem:	V21, V22, V22bis
Dialling Formats:	Pulse or DTMF
REN:	1.0
Telecommunication Standards:	CTR21

### Environmental

Operating Temperature:	10°C to +55°C
Maximum Humidity:	95% non-condensing

### Physical

Dimensions:	145mm x 90mm x 30mm
Material:	Polycarbonate
Packed Weight:	150g

## Standards



2004/108/EC (CE directive): Hereby, Texecom declares that this device is in compliance with the essential requirements and other relevant provisions of Directive 2004/108/EC.



**WEEE Directive:** 2002/96/EC (WEEE directive): Products marked with this symbol cannot be disposed of as unsorted municipal waste in the European Union. For proper recycling, return this product to your local supplier upon the purchase of equivalent new equipment, or dispose of it at designated collection points. For more information see: [www.recyclethis.info](http://www.recyclethis.info).


## Warranty

All Texecom products are designed for reliable, trouble free operation. Quality is carefully monitored by extensive computerised testing. As a result the *USB-Modem* is covered by a two-year warranty against defects in materials or workmanship.

Due to our policy of continuous improvements Texecom reserve the right to change specification without prior notice.

## Wintex Options

Click Setup, Options... The Wintex Options window is displayed:



### Modem Idle Time-Out

When the PC modem is online with the control panel and there are communication tasks running (send or receive), Wintex will prompt you that the modem has been Idle after the time-out duration has elapsed. You can either choose to stay connected with the panel or hang-up as required.

### Default UDL Password -

The default UDL password is 1234

### Use Default UDL Password when Creating New Accounts

If this option is ticked the default UDL password (1234) will be set when creating a new customer account.

### Customer Files Folder

This option specifies where the customer files are located (by default they are stored in "C:\Program Files\Texecom\Wintex\Customers"). Click on the Browse... button to specify an alternative location e.g., a network server. click on the Default button to return the Customer Files Folder back to the default setting.



**NOTE** If you are using windows 7 (or service pack 2 or 3 of Vista) and you are not the admin on the PC (you may have admin rights, but this will apply if you are not the overall admin) then your customer files will be stored here;

C:\Users\\*NAME\*\AppData\Local\VirtualStore\Program Files\Texecom\Wintex\Customers\


or for 64Bit systems C:\Users\\*NAME\*\AppData\Local\VirtualStore\Program Files (X86)\Texecom\Wintex\Customers\

# Programming the Control Panel


## Zones & Attributes

Click Programming/Zones and Attributes... or click on the Zones button on Panel Program Bar. The Zones and Attributes window is displayed:

### Premier 412/816 Zones and Attributes window



### Premier Elite 24/48/88/168 & 640 Zones and Attributes window



To select a zone click on the required zone in the left hand panel.

With the required zone selected, Edit the options as required.

To close all Panel Programming windows, click on the Close button on the Panel Program Bar.

#### Include Zone Text on Send/Receive

If this option is ticked then the zone text is included on a send/receive. If this option is not ticked the zone text is included on a send/receive, this will improve the send/receive time.

#### Include All Zones on Send/Receive (Premier Elite 24/48/88/168 & 640 Only)

If this option is ticked then the data for all zones is included on a send/receive, i.e., if the panel type is a Premier 168 then the data for all 168 zones is included on a send/receive. If this option is not ticked then only the data for the zones that are fitted are included on a send/receive, this will improve the send/receive time for systems that are not fully expanded.


#### Copying Zone Data

1. Right click on the zone in the left hand panel that you want to copy.
2. A popup menu will appear. Click on Copy to copy the zone information.
3. Right click on the zone that you want to copy the information to.
4. A popup menu will appear. Click on Paste to paste the information


## Programming Areas/Partitions Timers & Options

Click Programming|Partition/Area Timers and Options... or click on the Partitions button on Panel Program Bar. The Partition Timers and Options window is displayed:

### Premier 412/816/816 Plus & 832 Partition Timers and Options window



### Premier Elite 24/48/88/168 & 640 Area Timers and Options window



To select a partition/area click on the required partition/area in the left hand panel.

With the required partition/area selected, Edit the options as required.

To close all Panel Programming windows, click on the Close button on Panel Program Bar.

### Copying Partition/Area Data


1. Right click on the partition/area in the left hand panel that you want to copy.
2. A popup menu will appear. Click on Copy to copy the selected partition/area information.
3. Right click on the partition/area that you want to copy the information to.
4. A popup menu will appear. Click on Paste to paste the information.




## Programming Global System Options

Click Programming|Global System Options... or click on the Global button on Panel Program Bar. The Global System Options window is displayed:

### Premier 412/816/ 816 Plus & 832 Global System Options window



### Premier Elite 24/48/88/168 & 640 Global System Options window



This window contains multiple pages of options, to select a page click on the required tab (Timers, Configuration Options, Control Timers etc).With the required page selected, Edit the options as required. To close all Panel Programming windows, click on the Close button on the Panel Program Bar.

### Language

The Language chosen will not show in Wintex until it has been changed in the control panel. Languages available are as detailed in the table below.

24/48/88/168				640			
Identifier	LS1	LS2	LS3	Identifier		Identifier	
0	English UK	English UK	English UK	0	English UK	8	Italian
1	English	English	English	1	English	9	Polish
2	Swedish	Spanish	Russian	2	Swedish	10	Hungarian
3	French	Italian	Slovenian	3	French	11	Russian
4	Belgian Dutch	Polish	Czech	4	Belgian Dutch	12	Slovenian
5	Text Danish	Hungarian	German	5	Norwegian	13	Czech
6	Norwegian		Estonian	6	Finnish	14	German
7	Finnish			7	Spanish	15	Estonian

### Country Code

Country code selection chooses the defaults loaded in the panel, and is normally linked to the language chosen.

Country	Code	Defaults	Country	Code	Defaults
Export	0	UK	Denmark	45	Denmark
Russia	7	UK	Sweden	46	Sweden
South Africa	27	South Africa	Norway	47	Norway
Netherlands	31	UK	Poland	48	UK
Belgium	32	Norway	Germany	49	UK
France	33	France	Finland	58	Norway
Spain	34	UK	Australia	61	Australia
Hungary	36	UK	Test	97	UK
Italy	39	UK	Themes	98	UK
Czech	42	UK	Chinn	99	UK
UK	44	UK	Estonia	172 (372)	UK

### Restart Soak Test Timer

When you change the Soak Test Timer option this option is automatically ticked. When you send this page or send all configuration data to the control panel, Wintex will instruct the control panel to restart the Soak Test Timer.

### Restart Service Timer

When you change the Service Interval Timer option this option is automatically ticked. When you send this page or send all configuration data to the control panel, Wintex will instruct the control panel to restart the Service Timer.


### Restart Battery Test Timer (Premier Elite 24/48/88/168 & 640 Only)

When you change the Battery Test Period Timer option this option is automatically ticked. When you send this page or send all configuration data to the control panel, Wintex will instruct the control panel to restart the Battery Test Timer.


## Remote Keypad Options

Click Programming|Keypad Options... or click on the Keypads button on Panel Program Bar. The Keypad Options window is displayed:

### Premier 412/816/816 Plus & 832 Keypad Options window



### Premier Elite 24/48/88/168 & 640 Keypad Options window



Select the keypad by clicking on the relevant keypad in the left hand panel.


With the required Keypad selected, Edit the options as required.

To close all Panel Programming windows, click on the Close button on the Panel Program Bar.

## Programming Expander Options


Click Programming|Expander Options... or click on the Expanders button on Panel Program Bar. The Expander Options window is displayed:

### Premier 412/816/816Plus & 832 Expander Options window




### Premier Elite 24/48/88/168 & 640 Expander Options window

Pre V6.16



V6.16 & Later




Select the Expander by clicking on the relevant Expander in the left hand panel.

With the required Expander selected, Edit the options as required.

To close all Panel Programming windows, click on the Close button on Panel Program Bar.

### Radio Expander (pre V6.16)




The Radio Expander page shows all of the Radio Devices on the system, the Device Type, The Serial Number and to which Zone/User the device is mapped. Not applicable to **Premier Elite™** V2.xx panels and **Ricochet™** MT2


## Programming Outputs

Click Programming | Outputs... or click on the Outputs button on Panel Program Bar. The Output Options window is displayed:

### Premier 412/816/816 Plus & 832 Output Options window



### Premier Elite 24/48/88/168 & 640 Output Options window



To select an output click on the required output in the left hand panel.

With the required output selected, Edit the options as required.

To close all Panel Programming windows, click on the Close button on the Panel Program Bar.

## Programming Communications Options

Click Programming | Communication Options... or click on the Communication button on Panel Program Bar. The Communication Options window is displayed:

### Premier 412/816 Communication Options window

### Premier Elite 24/48/88/168 & 640 Communication Options window

This window contains multiple pages of options, to select a page click on the required tab (Options, ARCs etc).

With the required page selected, Edit the options as required.

To close all Panel Programming windows, click on the Close button on the Panel Program Bar.

### Telephone Numbers

The following characters can be inserted in the telephone number:

" " = 3 second pause

"W" = 10 second pause


"#" = hash (normally used for pagers)

"\*" = star (normally used for pagers)


## Programming Users

Click Programming|User codes... or click on the User Codes button on Panel Program Bar. The User Code Maintenance window is displayed:

### Premier 412/816/816 Plus & 832 User Code Maintenance window



### Premier Elite 24/48/88/168 & 640 User Code Maintenance window



To select a user click on the required user in the left hand panel.

With the required user selected, Edit the options as required.

To close all Panel Programming windows, click on the Close button on Panel Program Bar.

### Copying User Data

1. Right click on the user in the left hand panel that you want to copy.
2. A popup menu will appear. Click on Copy to copy the user information.
3. Right click on the user that you want to copy the information to.
4. A popup menu will appear. Click on Paste to paste the information.


## Connecting with the control panel

Now you have set up your connection options, you can use the full functionality of **Wintex™**

To connect with the Control Panel:


Click Communications, Connect... or click on the Connect Button on the tool bar. You will be given a choice of connection options:

- Connect using PC Com
- Connect using Modem 1
- Connect using Modem 2
- Connect using Radio-Pad
- Connect Via Network (this option will only appear if you have programmed in IP details)



Click on the required connection option. Wintex will attempt to connect with Control Panel.

Once the connection is established the bottom status bar will show "On-line Ready". The status bar will also show the name of the **Wintex™** user accessing the system.

The menu and tool bar options will now change to "Hang Up". 

## Waiting for the Panel to Call

Use this command to put the PC modem into "Waiting for Panel to Call..." mode. Once in this mode the user at site should initiate the download sequence by selecting the "Start Download" command on the Control Panel:

Panel Type	Start Download Command
Premier 412	User Code + Menu + 9 + 94
Premier 816 & Plus	User Code + Menu + 9 + 94
Premier 832	User Code + Menu + 9 + 94
Premier Elite 24	User Code + Menu +Yes+ scroll until "Call Remote PC?" is displayed.
Premier Elite 48	User Code + Menu +Yes+ scroll until "Call Remote PC?" is displayed.
Premier Elite 88	User Code + Menu +Yes+ scroll until "Call Remote PC?" is displayed.
Premier Elite 168	User Code + Menu +Yes+ scroll until "Call Remote PC?" is displayed.
Premier Elite 640	User Code + Menu +Yes+ scroll until "Call Remote PC?" is displayed.

## Requesting a Call Back

This option is only enabled when you are connected to the control panel via a modem. Selecting this menu option will cause both the PC and control panel modem to hangup. The control panel will then call-back to the PC modem and re-establish the connection.

## Disconnecting from the Control Panel

To disconnect with the Control Panel:

Click Communications|Hang Up... or click on the Hang Up Button on the tool bar. The PC will disconnect with Control Panel.

The comms status bar will show "Off-line Ready".

## Connecting to Ricochet™ Monitor (V6.16 & Later only)

Connection can be made to launch and view Ricochet Expander(s) V2.xx & above data when connected to the control panel. The **Ricochet™** Icon turns green when online with the panel, clicking this button launches and connects to **Ricochet™** Monitor.



NOTE Should only be used on Local connections, or IP/GPRS connections if remote.

# Sending & Receiving Configuration Data

## Receiving

### Receive Configuration Data

The Receive Configuration Data option retrieves all configuration data (except communicator reporting codes) from the Control Panel.

Click Communications|Receive Configuration Data or click on the Receive button on the tool bar and select the Receive Configuration Data option. The Communication Status window will display progress of the communication:




When the communication task is completed you may disconnect with the Control Panel if required,

You can now edit the Control Panel data.

### Receive Panel Log

The Receive Panel Log... option allows you to retrieve the system event log from the Control Panel.

Click Communications|Receive Panel Log... or click on the Receive button on the tool bar and select the Receive Panel Log option. The Receive Event Log window is displayed:




Select the Receive Options:

**Receive All Events:** This option will retrieve all events from the Control Panel.

**Receive New Events Only:** This option will only retrieve the events that have occurred since the last Receive Panel Log.

**Receive the Last ## Events:** This option allows you to specify how many events to retrieve.

Click on OK to start. The Communication Status window will display progress of the communication:



When the communication task is completed you may disconnect with the Control Panel if required,


You can now view Control Panel log, see Viewing the Log on page 37.



## Receive All

The Receive All option retrieves all configuration data (including communicator reporting codes) and the system event log from the Control Panel.

Click Communications|Receive All or press CTRL+A or click on the Receive button on the tool bar and select Receive All (Data & Log) option. The Communication Status window will display progress of the communication:



When the communication task is completed you may disconnect with the Control Panel if required,

You can now edit the Control Panel data, or view Control Panel log.


## Receive Current Page

The Receive Current Page option retrieves the data for the active Panel Programming window, e.g. if you have the Program Zones and Attributes window active, selecting the Receive Current Page option will only retrieve data relating to Zones and Attributes.



**NOTE** This option is only available when one or more Panel Programming windows are open.

Click Communications|Receive Current Page or click on the Receive button on the tool bar and select the Receive Current Page option or click on the Receive Page button on the Panel Program Bar. The Communication Status window will display progress of the communication:



When the communication task is completed you may disconnect with the Control Panel if required,

## Receive Reporting Codes

The Receive Reporting Codes option allows you to select which group of communicator reporting codes to retrieve from the Control Panel.


Either from the Communications menu or the Receive button on the tool bar click Receive Reporting Codes. A sub menu will appear, from the sub menu select one of the following options:

- Pulse Codes: To retrieve the Pulse format communicator reporting codes (Premier 412/816/816 Plus & 832 Only).
- Contact ID Codes: To retrieve the Contact ID format communicator reporting codes.
- SIA Codes: To retrieve the SIA format communicator reporting codes.

## All Codes

To retrieve all communicator reporting codes.

The Communication Status window will display the progress of the communication:




When the communication task is completed you may disconnect with the Control Panel if required,

## Sending

### Send Configuration Data

The Send Configuration Data option sends all configuration data (except communicator reporting codes) to the Control Panel.

Click Communications|Send Configuration Data or press CTRL+D or click on the Send button on the tool bar and select the Send Configuration Data option. The Communication Status window will display the progress of the communication:



When the communication task is completed you may disconnect with the Control Panel if required,


### Update Configuration Data

The Update Configuration Data option only sends the configuration data that has been changed since the account was opened.



**NOTE** *In order for the update to work you MUST NOT save the changes that you have made since opening the account.*

Click Communications|Update Configuration Data or click on the Send button on the tool bar and select the Update Configuration Data option. The Communication Status window will display progress of the communication:



When the communication task is completed you may disconnect with the Control Panel if required,

You can now save the configuration data to disk by clicking on the Save button on the tool bar.


### Send Current Page

The Send Current Page option sends the data for the active Panel Programming window, e.g. if you have the Program Zones and Attributes window active, selecting the Send Current Page option will only send the data relating to Zones and Attributes.



**NOTE** *This option is only available when one or more Panel Programming windows are open.*

Click Communications|Send Current Page or click on the Send button on the tool bar and select the Send Current Page option or click on the Send Page button on the Panel Program Bar. The Communication Status window will display progress of the communication:



When the communication task is completed you may disconnect with the Control Panel if required,

## Send Reporting Codes

The Send Reporting Codes option allows you to select which group of communicator reporting codes to send to the Control Panel.


Either from the Communications menu or the Send button on the tool bar click Send Reporting Codes. A sub menu will appear, from the sub menu select one of the following options:

- Pulse Codes: To send the Pulse format communicator reporting codes (Premier 412/816 Only).
- Contact ID Codes: To send the Contact ID format communicator reporting codes.
- SIA Codes: To send the SIA format communicator reporting codes.

### All Codes

To send all communicator reporting codes.

The Communication Status window will display the progress of the communication:




When the communication task is completed you may disconnect with the Control Panel if required,

## Send/Read Time & Date

The Send/Read Time & Date option allows you to send the date and time to the Control Panel, it also allows you to read the current Date and Time of the Control Panel.

Click Communications|Send/Read Time & Date or press CTRL+T or click on the Send button on the tool bar and select the Send/Read Time & Date option.

The Send/Read Panel Date and Time window is displayed:



The Send Date and Send Time will default to the current date and time of the PC. If required adjust the date or time to the desired value, then click on the Send button.

The Panel Date and Panel Time display the actual date and time of the panel clock.


When finished Click Close to close the window.

# Diagnostics

## Online Status & Control

The On-line Status and Control mode allows you to view and control in real time the status of the alarm system.

Click Diagnostics|Online Status and Control... or click on the Online Status button on the tool bar. The Online Status and Control window will be displayed:




Click on the item you wish to view in the left hand panel (Zones & Outputs, System, Areas etc).

Click on the relevant control buttons to change the status of the Control Panel.

## Remote Control

Click on Remote control to bring up the controls for the panel, under this menu you can arm/disarm/reset the control panel, turn outputs on/off and send messages to the control panel.



Click on the Close button when finished.

## Online Keypad

The On-line Status and Control mode allows you to view and control in real time the status of the alarm system.

Click Diagnostics|Online Keypad... or click on the Online Keypad button on the tool bar. The Online Keypad window will be displayed:




Click on the keys to operate the online keypad.


Click on the Close icon in the top right hand corner when finished.

## Event Log











Click Diagnostics|View Event Log... or press CTRL+L or click on the Event Log button on the tool bar. The Control Panel Event Log window is displayed: (at default there will be no log as one has not been downloaded)



See Receive Panel Log on page 32 to populate the Panel Log window




## Event Log Buttons

Icon	Button	Function
	Refresh Log	Loads the log in memory into the log viewer.
	Load Log	Load a previously saved log into the log viewer.
	Save Log	Saves the log to the customer log file.
	Append Log	Appends the log to an existing customer log file.
	Save As...	Saves the log to a text file.
	Clear Log	Clears the contents of log viewer.
	Print Log	Prints the contents of the log viewer.
	Receive Log	Opens the Receive Log window, see Uploading the Control Panel Log.
	Filter	Opens the Log Event Filter window and allows you to filter events in the log viewer.
<input type="checkbox"/> Mandatory Events	Mandatory Events	When checked shows only the mandatory event log
	Close	Closes the Event Log Viewer

## Remote/Anti Code Reset

All Premier Elite Control Panels have a Random Number Remote Reset feature. This option allows you to generate the Remote Reset number.

Click Diagnostics | Remote Reset Generator... or press CTRL+R. The Remote Reset window is displayed:




Enter the number that you require to decode in the Input Number box. The Remote Reset number is then displayed in Reset Number Box.

Click on the Close button to close the Remote Reset window.




## Changing the Language

If you wish to change the language Wintex™ uses;  
Click Setup, Language... The language options are displayed:



After making your choice of language the following dialog box will be displayed;



After closing and re-opening Wintex the new language will be displayed;





# Menu Commands

## User

### Log On...

- Log Off
- Change Log On Password...
- Change User Name...
- Change User Access...
- Exit

## Accounts

### New Account...

- Open Account...
- Edit Account...
- Save Account
- Save Account As...
- Revert Account Data
- Close Account
- Account History
- Print Account and Panel Details...
- Backup Account Data...
- Restore Account Data...

## Programming

### Zones and Attributes...

- Partition Timers and Options...
- Global System Options...
- Remote Keypad Options...
- Expander Options...
- Outputs...
- Communication Options...
- User Codes...

## Communications

### Connect/Hangup

- Waiting For Panel to Call
- Request Call-back
- Receive Configurations Data
- Receive Panel Log...
- Receive All (Data & Log)
- Receive Current Page
- Receive Reporting Codes
- Send Configuration Data
- Update Configuration Data
- Send Current Page
- Send Reporting Codes
- Send/Read Time & Date...

## Diagnostics

### Online Status and Control...

- Online Keypad...
- View Event Log...
- Remote Reset Generator...
- Online Printer Mode...

## Setup

### Modem Setup...

- Modem Database...
- Options...
- Language

## Utilities

### Panel Language Editor



*NOTE Only available with TexecomMaster Logon. Please see Panel Language Editor Section on page 43 .*

## Window

### Tile

















- Cascade
- Arrange icons

## Help

### Contents

- About..

## Tool Bar Commands

Icon	Button	Function
	New	Opens the New account window and allows you to create a new customer accounts.
	Open	Opens the customer accounts window and allows you to open an existing account.
	Save	Saves all account and Control Panel data to disk.
	Edit Account	Opens the Control Panel programming button bar.
	Program	Opens the Programme Menu
	Print	Open the Print options window.
	Receive	Opens the Receive options menu.
	Send	Open the Send options menu.
	Rem.Reset	Opens the Remote Reset Generator.
	Diagnostics	Opens the Online Status and Control window.
	Keypad	Opens the Online Keypad window.
	Event Log	Opens the Control Panel Event Log Viewer.
	Setup	Opens the Modem Settings & Options window
	Connect	Establishes a connection with the Control Panel.
	Hangup	Closes the connection with the Control Panel
	Ricochet QuickConnect	Launches & connects to Ricochet Monitor (V6.16 & later only)

# Panel Language Editor Premier 412/816/ & 832

## Introduction


Wintex is equipped with a Language Editor which allows the user to create custom translated language files for the Premier 412, 816, 816 Plus & 832 Control Panels. Once the new language file has been created the user may use Wintex to install the language on the panel, or subject to approval may have the language installed as their standard default language at the manufacturing stage.

The language editor is a hidden function which can be easily enabled to allow translation for all text displayed on the keypads.


## Enable Panel Language Editor

To enable the Language Editor proceed as follows:-

Click User Change User Access




Click Add New User



Create the new user using the following credentials

User Name: TexecomMaster

 NOTE This is case sensitive

Password 123456

Click OK to add new user.

Click OK to exit User Configuration.


Now click User Log Off.

Click User Log On enter the following:-

**User Name TexecomMaster**

**Password 123456**

The following pop up will be seen




Click OK

Log On to Wintex using your normal User Name and Password



**NOTE** If you have not created your own profile the default User Name is Master and the Password is 123456.

When you are logged on you will now see an extra Toolbar item called Utilities.




## Using Panel Language Editor

To be able to use the Language Editor you first need to open an account.

Click on New

In the Account Reference Filed Type Translation



In the Panel Details Tab Select Premier 832 from the Dropdown Menu and Click Add.



**NOTE** It is important that 832 is selected as this will then cover all panel types, if you select 412 at this stage many of the options in the 832 will not be available in the Language Editor and will not be translated.


## Starting Translation

Next Click on Utilities in the Menu Bar, and click Panel Language Editor. You will be presented with the following screen.




*NOTE It is possible to load one of the existing translated languages to use as the basis for the new translation.*

Click on the Current Text Column on the right hand side, your screen should look like this




Click on the Edit button and you should see this



You can now edit the text in the Event Text Window and it will be displayed in the Sample Display Window below. Do this for every line of text in the Panel Text tab and then complete for each of the other Tabs.

## Inserting Special Characters

If you need to insert special characters, the available characters can be viewed by selecting the Character Map. Highlight the character required and click Select. Once you have completed your selection Click Insert.



## IMPORTANT NOTES

### The # symbol

Where you see the # symbols in the text you are editing they must be the same symbol and in the same place and of the same number.

For Example if I want to translate Line 11 from English to Greek the original text looks like this

#### Zone ## Text

The Translation will be

**Ζώνη ## Κείμενο**

### The ? symbol

The same rule applies to the ? symbol where this is present in the text it must be in the translated text in the same format and the same number of times

For example if I want to edit Line 002 from English to Greek the original looks like this

#### Enter Code > ??

The translation will look like this

**Εισάγετε Κωδικός > ??**

Once all of the translations have been completed save the file. By default this will be saved in the Languages Subdirectory of Wintex.


## Updating the Panel Language

Before updating the panel language, please make sure you have saved the new language to disk.

Create a new account and fill in all of the relevant details.

Connect to the panel

The language can then be sent to the panel from the Communications Menu as shown below.



Please send the completed translation files to [techsupport@texe.com](mailto:techsupport@texe.com) so they may be included in future versions of the Premier range of control panels.



**NOTE** *only complete translations will be put into Control Panels. If you wish to use your translated file locally then you can do this by using the "Send All" or "Send Page" buttons in Panel Language Editor. If you choose to use the language file and at some point in the future you have to load the panel defaults the locally stored language will be lost and the default panel language re-loaded.*

# Language Manager for Wintex™

Language Manager is a utility which allows you to translate Wintex™ into your chosen language

## Starting Translation

1. Ensure that the correct version of **WINTEX** is installed on the PC that is going to be used to do the translation.
2. Install the Language Manager (It is advisable to install it in the same folder as **WINTEX**).




**NOTE** The Language Manager .EXE file can be found in the directory C:\Programme Files\Texecom\Wintex\Language Manager.

3. Run the Language Manager software (The shortcut is in the **WINTEX** Program folder on the start menu).
4. After the program has started, click on File|Open Project... and open the file called “Wintex.ntv.Ing”.
5. If your language was installed at step 2 go to step 7 otherwise click on File|Create New Language... the following screen is displayed:



6. Select your language from the Language Identifier list then click OK.
7. In the main screen ensure that the “Units.WintexStrings” is selected as shown below:



**NOTE** The Native Language (English) can be hidden by un-checking the “Show Native Language” check box on the main screen.

Translate the text in each cell (click on the cell and press F2 or click twice on the cell). All un-translated cells are marked with a little blue triangle. See Notes for Translation on page 49




## Creating a New Language .DLL file

Once you have translated some or all of the text (you don't have to translate all the text in one go), you need to create a Language DLL file. **This operation only needs to be performed once.** Before you create the DLL you need to select the Program Execution (PE) File. Click on File|Select PE file... and select the Wintex.EXE file as shown:

Now click on File|Create DLL this will create a language DLL file. **Note:** The "Create DLL" option is only enabled if your language is selected, to select your language click on any cell in your language column.

Once the DLL has been created you can test your translated file by running Wintex and going to Setup|Language and selecting the relevant language.

Continue to translate the text, when you want to test your work click on File|Save Language then click on File|Synchronize DLLs. This will update the language DLL and will allow you test the updated file in **WINTEX**



## Notes for Translation

### Accelerator Keys:

Most Windows menus and buttons have shortcut key that can be accessed by pressing the ALT key followed by the underlined letter of menu or button. For example the Accounts menu can be selected by pressing ALT followed by A. The strings in the language file will have the ampersand (&) character before the letter that will be underlined, so when you look at the text for the Accounts menu you see that it is written as "&Accounts". If you want to use the ampersand character in the string then you must insert two. For example the Send PC Time & Date menu option is displayed in **WINTEX** as "Send PC Time & Date" (shortcut = T), the text in the language file is written as "Send PC &Time && Date".

### Formatted Strings:

Some strings within the language file have special format specifiers, all specifiers start with the % character, for example "Control Timer %d".

%d is used to specify that a number will be inserted in the string, e.g. "Control Timer %d" can be displayed as "Control Timer 3".

%.2d is used to specify that a two digit number will be inserted in the string, e.g. "Zone %.2d" can be displayed as "Zone 02".

%.3d is used to specify that a three digit number will be inserted in the string, e.g. "Zone %.3d" can be displayed as "Zone 002".

%s is used to specify that a string will be inserted in the string, e.g. "Do you want to save the account "%s" ?" can be displayed as "Do you want to save the account "My Test 816 Panel" ?"

It is **very important** that the format specifiers remain included when the string is translated.

## Future Versions of WINTEX™

It is very important that once the translation is complete, that the language file is emailed back to **Texecom** this is so that when future versions of Wintex are released, the language files can be refreshed to include any new strings. If the file is not sent back you will have to translate all text again when next revision of **WINTEX** is released.

The language file is "Wintex.XXX.Ing" where XXX is the country abbreviation code as shown at step 5, for example the Spanish abbreviation code is ES so the language file name is "Wintex.ES.Ing"

# **Texecom**

## **Designed to Perform**

Texecom Limited, Bradwood Court, St. Crispin Way, Haslingden, Lancashire BB4 4PW, England.

**Technical Support:**

UK Customers Tel: 08456 300 600

(Calls charged at 3.36 pence per minute from a BT landline. Calls from other networks may vary.)

International Customers Tel: +44 1706 233875

Email: [techsupport@texe.com](mailto:techsupport@texe.com)

© Texecom Limited 2012

**INS549-2**

