NetManager

- Multi Channel Monitoring
- Manages NetCam, NetServer and NetDVR
- Live viewing of up to 16 units
- Alarm image notification
- Playback of 4 Net-DVR devices simultaneously
- Scheduled 8 channel recording
- Scheduled back-up
- Status monitoring
- Alarm logging



The NetManager is a software package that supports up to 100 NetCam, NetServer and NetDVR units (or up to 400 camera channels). Up to 16 channels, from different locations, can be viewed simultaneously. In addition, the NetManager can control P/T/Z (and preset positions using the NetServer-I) from AutoDome and PTZ cameras.

NetManager allows you to view and record images from any unit of the NetCam, NetServer or NetDVR devices.

With the NetManager you can monitor live images, playback recorded images, make a quick recording, run a scheduled recording, run scheduled back-ups, and track alarms all through a single computer.

The high quality and solid reliability found in the NetCam, NetServer and NetDVR products come together with the NetManager Control Software.

NetManager is a comprehensive solution for total remote surveillance.





Workshop



Workshop

- Program startup from a dedicated window.
- Administrator or user level access.

Monitoring



Monitoring Program

- Simultaneous monitoring of 1, 4, 7, 10, 13, or 16 channels.
- Group creation with multi-channels and auto-sequence between channels within a group or among several groups.
- Map creation with multi-channels and auto-sequence between channels within a map or among several maps.
- Pop-up image for quick response to event triggers.
- PTZ control (on-screen control) for external dome or PTZ cameras.
- Preset control for AutoDomes in combination with NetServer-1.
- Single image capture in BMP format.

Playback



Playback Program

- Simultaneous playback with maximum 4 channels from any registered NetDVR device.
- Record data on NetDVR units and on the PC's Hard Disk Drives
- Print and Save individual images.
- Play speed control with fast and slow options.
- Recorded video format conversion to AVI with 'File Converter' utility.

Schedule Backup



Schedule Backup Program

- Backup scheduling per day or per weekly basis
- Data on a NetDVR HDD is backed up to NetManager PC's Hard Disk Drive.
- Logging of backup schedule and backup result.
- Running status check with all scheduled NetCams.

Schedule Recording



Schedule Recording Program

- Recording scheduling for one-time, daily, weekly, or monthly.
- Data recorded on NetManager PC's Hard Disk Drive.
- Multi-scheduling for 8-channel recording.
- Logging of recording schedule and backup result.

Alarm Tracer



Alarm Tracer Program

- Tracking all events from all connected NetDVR devices through motion detection and external sensors.
- Maintain log of tracing result.
- Event triggered live image window pops up when the event log is selected.

Setup Assistant



Setup Assistant

- Fast access to all devices in the network.
- Registration of remote devices.
- Registration of users and user access.

SPECIFICATIONS

Model Number: NetMan

NetManager:


PC requirements:

Processor: Pentium III 500 MHz or better

More then 64 MB of free memory

Video card with 16 MB video RAM or more

Operating System: Windows 2000



Live Image Monitoring and Playback on a Network