VIDEO LAUNCH AMPLIFIER

TYPE BH72 DATA SHEET

- Coaxial input / Coaxial output
- Suitable for colour or monochrome signals
- Adjustable for overall gain and high frequency lift
- 12V dc 15mA fully loaded



APPLICATION

Using a Video Launch Amplifier at the camera end of the cable run will improve the quality of the video signal received at the monitor or other receiving equipment. This unit is designed to operate on its own for short cable runs or in conjunction with a Video Line Corrector for medium/long cable runs.

The unit has internal controls for overall signal amplitude and high frequency lift to give the installer precise control.

Power consumption fully loaded is only 15mA and the unit can be powered from the camera power supply.

Addlestone Electronics Ltd. DESIGNED AND MANUFACTURED IN UK

TECHNICAL DATA

INPUT IMPEDANCE Internally terminated in 75 ohms (unbalanced).

SIGNAL TYPE Unit suitable for colour or monochrome signals

INPUT SIGNAL Nominal 1 volt peak to peak.

AMPLITUDE

OUTPUT SIGNAL Nominal 1 volt peak to peak terminated in 75 ohms.

AMPLITUDE

AT UNITY GAIN Differential Phase < 3 degrees / Differential Gain < 3%.

INTERNAL Variable from -3dB to +6dB.

GAIN CONTROL

INTERNAL HF Variable from -3dB to +6dB.

LIFT CONTROL

OUTPUT PROTECTION Output is protected against shorted or open circuit line.

INPUT-OUTPUT Input and output connectors are 75 ohm BNC type. CONNECTIONS

POWER REQUIREMENTS +12V dc supply. The unit is protected against a

reversed supply input.

POWER CONSUMPTION Approximately 0.2 watts.

PERMISSIBLE AMBIENT -10°C to +40°C.
OPERATING TEMPERATURE

EQUIPMENT CASE Housed in a grey polystyrene case, designed for free

DETAILS standing use.

WEIGHT OF EQUIPMENT 85 grammes.

DIMENSIONS OF Height 32mm

EQUIPMENT Depth 88mm excluding connectors

Width 51mm





ADDLESTONE ELECTRONICS LTD.

Springfields, Church Lane, Bisley, Woking, Surrey, GU24 9EA

Telephone: (01483) 480969 Fax: (01483) 797268 E-mail: sales@addlestone-electronics.co.uk Web Site: www.addlestone-electronics.co.uk