

KIN TOUCH PANEL MEET



Reference: 1445

FUNCTIONS

CALL TENANT

Visitors are able to call the desired tenant from the General Entry or the Block Entry. It is possible to use numbers (0-9) and letters (A-H)

- General Entry: Visitors need...

DESCRIPTION

FUNCTIONS

CALL TENANT

Visitors are able to call the desired tenant from the General Entry or the Block Entry. It is possible to use numbers (0-9) and letters (A-H)

- General Entry: Visitors need to enter from 1 to 3 digits block number followed by a 4 digits apartment number. For example, if the addressee lives in block 10 apartment 10H, the visitor shall enter: 10010H

- Block Entry: Visitors need to enter from 1 to 4 digits apartment number.

For example, if the addressee lives in apartment 2B, the visitor shall enter 2B only.

AGENDA

It is possible the visitors call tenants by means of selecting them on the electronic directory. The directory has a capacity of 10.000 users (name and apartment number). The agenda is managed by means of the integrated webserver.

CALL TO GUARD UNIT

I lf the visitor or tenant needs to be assisted, they are able to call up to two Guard Units that can be assigned to each panel. This call can be made from both General Entry and Block Entry. Up to 98 different guard units can be called (9901...9998)



It is possible to add up to 4 additional realys.(One Module Ref.1491 is required). Tenants can then open additional doors (garage, corridors, etc.), when called from any panel in their block or main entrance.

ACCESS PIN CODE

It is possible to define up to 8 access codes (pin) for the users can open the door. Codes can have 4 to 6 digits long and may be changed through the integrated webserver.

FACE RECOGNITION

Tenants can be identified in the front of the panel, and then the door been opened by means of pressing A key. This operation can automatically disable the alarm in their house.

ACCESS CONTROL

The panel includes a Mifare card reader that controls up to 100.000 cards. It is possible to manage cards by means of the MEET Management Software. In addition, the panel can be connected, to third party access control units through Wiegand 26 protocol.

IP CAMERAS

It is possible to configure up to 4 IP cameras that can be used as an auxiliary camera from all the monitors installed in the same block. These cameras can be used for tracking visitors through the corridors or common areas in the condominium.

VIDEO STREAMING

RTSP video stream can be constantly sent to NVR or third-party system so that the panel camera can be used as a regular CCTV camera for surveillance purposes. RTSP video stream and face recognition can not work simultaneously.

TAMPER

The panel is protected against vandalism thanks to the tamper alarm switch, so in case the panel is removed from its flush box a warning message will be sent to concierge and/or MEET Management Software.

TECHNICAL SPECIFICATIONS

System:

- CPU: Quad-core Cortex[™]-A7 1.5GHz
- GPU: Mali400MP2
- FLASH: 8GB eMMC Flash
- SDRAM: 1GB DDR3L

Screen:

- 10,1" Color TFT
- Resolution 1024 x 600 pixel
- View angle: 130° H, 140° V
- Contrast: 800/1
- Brightness: 300cd/m2

Audio Features:

• G.711/G 729 codec

Camera:

- 1/3" CMOS Color
- 120° diagonal Lens, Horizontal 105°, Vertical 55°
- 1280 x 720 pixel
- Minimum Illumination 0.5 LUX.



Automatic white led activation

• AWB

Power Consumption:

- On standby: 250 mA
- Working: 1000 mA
- With heater active (*): 1500 mA

Working voltage:

- 12 Vdc
- PoE (*)

Connectivity:

- Ethernet RJ-45 Connector
- RS485 connection port for lift control
- Secondary access control reader connection (Wiegand 26)
- Built in web server for configuration and remote management

Working Environment:

- Temperature: -40 oC.. + 70 oC
- Humidity: 20 80% (Non-condensing)
- IP 54

Size of product when packed: 14x46,5x25,5 cm

EAN 13: 8,4243E+12